

# FA FISCHER AMPS


## HARDWIRED IN EAR BODYPACK Art. No. 001100

### POSITION MODE SWITCH (STEREO)

### SETUP TO CONNECT IN **STEREO** MODE



#### HARDWIRED BODY PACK XLR INPUT 1/2



INPUT  
LEFT/1



MIXING CONSOLE  
XLR OUT LEFT


INPUT  
RIGHT/2



MIXING CONSOLE  
XLR OUT RIGHT



#### HARDWIRED BODY PACK XLR INPUT 1/2



INPUT  
LEFT/1



MIXING CONSOLE  
SYMMETRIC JACK OUT  
LEFT


INPUT  
RIGHT/2




MIXING CONSOLE  
SYMMETRIC JACK OUT  
RIGHT



#### HARDWIRED BODY PACK XLR INPUT 1/2




INPUT  
LEFT/1




MIXING CONSOLE  
JACK OUT  
ASYMMETRIC LEFT

INPUT  
RIGHT/2



MIXING CONSOLE  
JACK OUT  
ASYMMETRIC RIGHT




### SETUP TO CONNECT IN MONO-MIX MODE

### POSITION MODE SWITCH (MONO-MIX MODE)



#### HARDWIRED BODY PACK XLR INPUT 1/2



INPUT  
LEFT/1




INPUT  
RIGHT/2



MIXING CONSOLE  
SIGNAL 1

MIXING CONSOLE  
SIGNAL 2



#### HARDWIRED BODY PACK XLR INPUT 1/2



INPUT  
LEFT/1




INPUT  
RIGHT/2



MIXING CONSOLE  
SYMMETRIC JACK OUT  
SIGNAL 1

MIXING CONSOLE  
SYMMETRIC JACK OUT  
SIGNAL 2


#### HARDWIRED BODY PACK XLR INPUT 1/2



INPUT  
LEFT/1



INPUT  
RIGHT/2



MIXING CONSOLE  
JACK OUT  
ASYMMETRIC SIGNAL 1

MIXING CONSOLE  
JACK OUT  
ASYMMETRIC SIGNAL 2

**IN MONO-MIX MODE MODE THE  
PAN- CONTROL CHANGES THE  
SIGNAL RATIO BETWEEN  
INPUT SIGNAL 1 AND SIGNAL 2**

# FISCHER AMPS


## HARDWIRED IN EAR BODYPACK Art. No. 001100

### POSITION MODE SWITCH (MONO)

#### SETUP TO CONNECT IN MONO MODE




#### HARDWIRED BODY PACK XLR INPUT 1/2




INPUT  
LEFT/1



MIXING CONSOLE  
XLR OUT



#### HARDWIRED BODY PACK XLR INPUT 1/2




INPUT  
LEFT/1




MIXING CONSOLE  
SYMMETRIC JACK OUT



#### HARDWIRED BODY PACK XLR INPUT 1/2



INPUT  
LEFT/1



MIXING CONSOLE  
JACK OUT  
ASYMMETRIC

